

HELPFUL RESOURCES

- [Tool Demo: Bohle Studio Circle Cutter](#)
- [Preparing Kiln Shelves](#)
- [Fusing Basics](#)
- [Coldworking with Diamond Hand Laps](#)
- [Coldworking with a Wet Belt Sander](#)
- [Slumping Basics](#)

FEATURED PRODUCTS

- [Petrified Wood with Clear \(002971\)](#)
- [Robin's Egg Blue 3mm \(000161\)](#)
- [Bowl Mold \(8652\)](#)
- [Bohle Studio Circle Cutter \(7161\)](#)
- [Diamond Hand Laps \(7220, 7221, 7222\)](#)
- [Shelf Primer \(8220\)](#)
- [Suction Lifter \(7195\)](#)
- [Running Pliers \(7008\)](#)

ADDITIONAL ITEMS

- Ruler
- Wet Belt Sander

FUSING THE BLANK SCHEDULE

	RATE	TEMPERATURE	HOLD
1	300° F (166° C)	1225° F (662° C)	1:00
2	600° F (333° C)	1490° F (810° C)	:10
3	AFAP	900° F (482° C)	1:00
4	100° F (55° C)	700° F (371° C)	:00
5	AFAP	70° F (21° C)	:00

SLUMP & FIRE-POLISH SCHEDULE

	RATE	TEMPERATURE	HOLD
1	300° F (166° C)	1180° F (637° C)	:15
2	AFAP	900° F (482° C)	1:00
3	100° F (55° C)	700° F (371° C)	:00
4	AFAP	70° F (21° C)	:00