

Petrified Wood and Robin's Egg Blue Bowl

Featured Products

- Petrified Wood with Clear ([002971](#))
- Robin's Egg Blue 3 mm ([000161](#))
- Bowl Mold ([008652](#))
- Bohle Studio Circle Cutter ([007161](#))
- Diamond Hand Laps ([007220](#), [007221](#), [007222](#))
- Shelf Primer ([008220](#))
- Suction Lifter ([007195](#))
- Running Pliers ([007008](#))

Helpful Resources

- [Tool Demo: Bohle Studio Circle Cutter](#)
- [Preparing Kiln Shelves](#)
- [Fusing Basics](#)
- [Coldworking with Diamond Hand Laps](#)
- [Coldworking with a Wet Belt Sander](#)
- [Slumping Basics](#)

Additional Items

- Ruler
- Wet Belt Sander

Fusing the Blank Schedule

	RATE	TEMPERATURE	HOLD
1	300 °F (166 °C)	1225 °F (662 °C)	1:00
2	600 °F (333 °C)	1490 °F (810 °C)	0:10
3	AFAP*	900 °F (482 °C)	1:00
4	100 °F (55 °C)	700 °F (371 °C)	0:00
5	AFAP*	70 °F (21 °C)	0:00

Slump & Fire Polish Schedule

	RATE	TEMPERATURE	HOLD
1	300 °F (166 °C)	1180 °F (637 °C)	0:15
2	AFAP*	900 °F (482 °C)	1:00
3	100 °F (55 °C)	700 °F (371 °C)	0:00
4	AFAP*	70 °F (21 °C)	0:00