

PRODUCTS FOR THIS PROJECT

Clear Transparent powder (001101-0008-F)
Mineral Green Opalescent sheet (000117-0030-F)
Red Opalescent sheet (000124-0030-F)
Black Opalescent sheet (000100-0030-F)
Midnight Blue Transparent sheet (001118-0030-F)
Tekta Clear sheet (001100-0680-F)
Deep Cobalt Blue Opalescent sheet (000147-0030-F)
Toyo Self-Oiling Cutter (7010)
Bohle Silberschnitt Cutting Fluid (7157)
Spartan Glass Cleaner (8236)
Paragon BenchTop-16 Kiln (8852)

FIRING SCHEDULES FOR THIS PROJECT

Rapid Heating to Avoid Firing-Induced Crystal Formation

	RATE	TEMPERATURE	HOLD
1	300°F (167°C)	1225°F (663°C)	:45
2	600°F (333°C)	1490°F (810°C)	:10
3	AFAP	900°F (482°C)	1:00
4	100°F (56°C)	700°F (371°C)	:00
5	AFAP	70°F (21°C)	:00